USER'S MANUAL BOSS Beds 540



Table of Contents

Safety Instructions	
Parts List	03
Under Bed View	04
Electronics Overview	05
Installation	06
Wireless Remote Control	08
Remote Pairing	
Memory Setting	12
Setting Up Two Bases	
Headboard Bracket Installation.	14
Trouble Shooting	15

Safety Instructions

Safety Disclaimer

Thank you for purchasing a Bossbeds adjustable bed base. For your safety, please read all instructions carefully before using this adjustable base. Save these instructions for future reference.

Attention:

Keep the base unplugged from the electrical outlet before operating any part of the base. To prevent the risk of electric shock, always unplug the base before cleaning. For your safety, ensure the base is in a flat position with all motors turned off, disconnected from the power source, and keep the power cord away from heated surfaces.

If the power cord or plug becomes damaged, or if the bed base is wet or not working properly, stop using the bed base and contact customer service

This bed base is intended to be used only as described in this manual. Do not use any accessories/attachments that are not recommended by the manufacturer. Close supervision is required when the bed base is used by or near children, convalescents or dis-abled persons.

Electrical Safety: Connect to a surge protector (not included).

Please ensure you connect the base properly to the power supply. Any incorrect power connection may cause electric Shock or Fire. FOR OPTIMAL SAFETY, YOUR ADJUSTABLE BED SHOULD BE PLUGGED INTO A SURGE PROTECTOR (not supplied with this adjustable bed). Always unplug this adjustable bed frame from the electrical outlet before any cleaning or maintenance of the bed frame. To safely disconnect, remove the plug from the outlet. Keep cord away from heated surface. Use only indoors.

The control box, motors, and remote (except battery compartments) should not be opened or tampered with. Opening or tampering with these components without authorization will void the warranty.

In-Home use only

Bossbeds adjustable bed bases are designed exclusively for in home use only. Do not use this base with oxygen therapy equipment or near explosive gases.

Pacemaker Notice:

This bed base contain noedymium magnets which may interfere with magnetic fields of devices such as pacemakers, ICD'S etc. Some pacemakers may falsely interpret the optional massage vibrations as movement or exercise. The owner of such medical devices should consult their physician before using this product.

Children and Pets:

This product is designed to be used by an adult. Do not allow children to operate this bed without adult supervision. Immediately dispose of all packing materials as they can pose a smothering risk to children and pets. Injury could occur if children or pets are permitted to play on or under the bed.

Safety Instructions

Product Ratings:

The lift motors are not designed to operate continuously for more than (2) minutes in an (18) minutes time period. Attempting to circumvent or exceed this rating will shorten the life expectancy of the product and may void the warranty.

Weight Limits:

This product is not rated to support weights exceeding 385 kgs including the mattress and bedding The base will structurally support this weight, provided it is evenly distributed across the bed base. The adjustable base is not designed to support or lift this amount in the head or foot sections alone. Exceeding this weight restriction could damage the bed and/or cause injury and will void the warranty.

Acoustics:

The massage function will emit a noticeable tone during operation. As the massage intensity level is increased, the tone will intensify. The volume of this tone is directly related to the location environment. For example, when demonstrated in a show room, the surrounding environmental noise will cover some of massage noise. However, when installed in a home setting with wooden floors, carpeted or not, the massage volume will be more noticeable. In normal base operation, the legs support of the base will create a contact noise with floor. When entering, exiting, or shifting weight on the base, this contact noise may be louder as the legs make contact. This is normal.

Fabric Care:

To prolong the life of your fabric, protect it from direct sunlight whenever possible. For spot cleaning, wipe area with a light damp sponge or vacuum with a soft brush attachment to remove particles. Keep at a minimum of 30cm (12 inches) away from direct heat sources. For deeper cleaning, blot liquid spills with a clean dry cloth. Wipe with a clean cloth dampened with warm water. Do not moisten excessively. A soft bristle brush may be used to remove ingrained soil. Avoid scratching by brushing gently. Wipe with a clean cloth dampened with warm water to remove residues. Dry in a shaded area away from direct heat. If persistent marks remain visible after cleaning, seek professional advice.

FCC Compliance:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

To comply with the FCC RF exposure requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding RF exposure requirement an void user's right to operate the device.

Radio Frequency: 2.4GHz

Parts List


Ensure you have received all the parts listed below before discarding the packing materials.

Parts List:

- A) Wireless Remote Control and AAA batteries [3]
- B) Legs and Washer 4]
- C) Mattress Retainer [1]
- D) Power Supply [1]
- E) Power Cord [1]
- F) Headboard Bracket [2] (Optional)
- G) Headboard T-Bar [2] (Optional)
- H) Large Washers [2] (Optional)
- I) Long Bolts M8 [4] (Optional)
- J) Short Bolt [8] (Optional)
- K) Small Washers [12] (Optional)
- L) Hex Key [1](Optional)
- M) Sync Cable [1] (Optional)
- N) Long Bolts M10 [2] (Optional)




Under Bed View



Electronics Overview

Not to Scale, Only for illustration purposes.

Read all illustrations and instructions before beginning the installation process.



Installation

STEP 1: Remove packing materials

Put the bed base in a desired place with the bottom of the box facing up. Remove box cover, take out all of the packing materials and put aside, Make sure not to puncture the bed with any sharp objects.



STEP 2: Remove the bed from the box

Remove the bed base from the box keeping the bottom of the base facing upwards. Install the 4 legs to the four corners as shown. Tighten the legs by hand. Ensure the legs are secured tightly.

P.S. Install the headboard brackets at the same time if attaching to a headboard. See the page 13.



STEP 3: Overturn the bed base carefully

Carefully turn the base over using two people. Do not lay the base on its side to prevent damage to the side button, fabric or legs.



STEP 4: Connect power supply

To prevent damage to the Power Supply (part D), please ensure the Power Supply is placed outside the perimeter of the adjustable base frame.

Plug the power cord into the power supply as shown.



Installation


STEP 5: Remote

After the base is connected to the power supply, install three AAA batteries into the remote battery compartment. See pages 9 and 10 to learn how to operate the remote.




STEP 6: Install mattress retainer

Locate the mattress retainer as shown below [1)];




Insert the mattress retainer into the hooks at the foot of the bed as shown [2)]. Slide the mattress retainer into place. Ensure it is securely tightened [3)].





Wireless Remote Control



Wireless Remote Control

Massage Feature



The HEAD button increases or decreases the head massage intensities.



The FOOT button increases or decreases the foot massage intensities



The ALL/OFF button shut off all massage features.



The MASSAGE model switch button, there are three massage models.



The buttons of 10MIN, 20MIN or 30MIN sets the massage feature to automatically shut off after 10MIN, 20MIN or 30MIN as set.



The one touch FLAT button returns the head and foot sections to a horizontal position.



Wireless Remote Control

Adjusting Features



The HEAD UP/DOWN button raises/lowers the head section of the base



The FOOT UP/DOWN button raises/lowers the foot section of the base



One touch ZERO GRAVITY preset position, adjust your legs to a higher level than your heart, to help relieve pressure off the lower back and promote body circulation.



One touch MEMORY A preset TV position.



One touch MEMORY B preset LOUNGE position.




Remote Pairing

Attention: All bases are set to the different DIP of the remote for easier use. You need to pair your remote if you need one remote controls two bases simultaneously. If using only one base normally, proceed to page 12.


STEP 1:

Push the DIP switch on the remote control to a desired position (different from the position on the other remote controls that are paired with other nearby bases) and insert the batteries.



STEP 2:

Press and hold the "LINK BUTTON" on the control box untill the LINK LED lights, then release the "LINK BUTTON", after that, the LINK LED flashes, now the control box are ready for pairing.



STEP 3:

Press and hold simultaneously the Head-Up button and Foot-Up botton on the remote control untill backlight LED flashes, then release the two buttons. The backlight LED will keep flashing when it's searching the control box, once both of backlight LED of remote and LINK LED of control box stop flashing, the pairing operating is completed.



Very important: Pairing your device must be completed within 2 minutes; Make sure the other base in the room is powered off.

Stronger suggestion: Please use Sync Cable for operate two bases simultaneously (see page 13), more safer and higher effect.

Memory Setting

STEP 1:

Ensure the base is connected to the power supply correctly and the remote control works properly. Ensure the base is in the Flat position. Make sure the massage, LED light and other functions are turned off.

STEP 2:

Adjust the HEAD and FOOT to your desired position. Press the "TIMER/ALL OFF" button until all buttons on the remote are flashing.



STEP 3:

While the buttons are flashing, press one of these three buttons "MEMORY A"/"MEMORY B"/"ZERO GRAVITY" until the flashing stops. The selected MEMORY FUNCTION is now set.



Setting Up Two Bases

How to operate two bed bases simultaneously

STEP 1:

Either Remote A or Remote B can control two bases simultaneously after connecting the power supply.

STEP 2:

The sync cord is needed when connecting two CK or TXL bases together.

STEP 3:

How to synchronize the two bases?

Use the sync cord connecting base A control box in sync port with base B sync port.

Sync port: SYNCHRO CNTL!

STEP 4:

After synchronization, any of the remotes can control the two bases synchronously.

The same of the sa





Sync Cord

How to disable the synchronizing function

Unplug the sync cord connecting the two bases. The sync function is now disabled.

Remote A



Remote B



Headboard Brackets Installation

STEP 1:

Open the headboard bracket accessory package and confirm that all the pieces listed below are included: Headboard Brackets [2] Headboard Connecting Components [2] Short Bolts (8) Long Bolts M8 [4] Large Washers [2] Small Washers [12] Hex Key [1] Long Bolts M10 [2]

STEP 2:

Install the headboard bracket (F) using one long bolt (M10) and one large washer. Install as per the picture to the right. Use the Hex Key to tighten the bolts. Repeat this process for the other side of the base.



STEP 3:

Attach the headboard T-Bar (G) to the headboard bracket(F) using 4 short bolts and 4 small washers as per the picture to the right. Use the Hex Key to tighten the bolts. Repeat this process for the other side of the base.









STEP 4

The remaining 4 pieces of long bolts (M8) and 4 pieces of small washers can be used to attach the headboard bracket to your headboard.

Trouble Shooting

